

PhotoCross™ V2 Instructions

www.thinktankphoto.com

thinkTANK®

VENTURE · OBSERVE · CONNECT™

TRIPOD STRAPS



Step 1: Locate the two adjustable tripod straps. Open the gatekeeper clip on each end by squeezing the top plastic bar to release the metal gate.



Step 2: Slide the opened clip through the webbing loop and close it securely.

FRONT PANEL ATTACHMENT



Fasten the straps horizontally to the upper and lower front panel webbing loops, then wrap them around the tripod to secure it in place.

SIDE POCKET ATTACHMENT



Place the tripod legs into the side pocket, then use the built-in strap to secure the tripod to the bag.

RAINCOVER ATTACHMENT



Step 1: Locate the red loop and black web leash at the top of the rain cover.



Step 2: Place the rain cover over the top of the bag, then pull it downward over the rest of the bag until it fits snugly.



Step 3: Feed the black leash underneath the shoulder strap and through the red loop to secure the rain cover.

PhotoCross™ V2 Instructions

www.thinktankphoto.com



VENTURE • OBSERVE • CONNECT™

SIDE-HANDLE FOR EASY BAG REMOVAL



When removing the bag, use the side-handle to easily lift the bag up and over your head.

PERSONAL GEAR ATTACHMENT – EXPAND YOUR CARRY CAPACITY



Fasten the straps diagonally on the front panel to carry additional gear.

ZIPPER PULL SECURITY – IMPROVE SECURITY WHILE TRAVELLING



To help deter theft in crowded areas, take one external zipper pull and fit the T-shaped portion through the cord loop of the remaining zipper pull.

WAIST BELT ATTACHMENT AND STORAGE



Step 1: To attach, fasten the waist belt's gatekeeper clip to the webbing loop on the opposite side of where the belt is anchored.



Step 2: When not in use, tuck the waist belt into the pocket on the rear panel of the PhotoCross.

ADDITIONAL RESOURCES

Please visit our website for additional images and instructional videos:
www.thinktankphoto.com