# 5.5" OLED VERTICAL MONITOR



**User Manual** 

## **CONTENTS**

Foreword	1
Cautions	1
Key Features	1
Product Overview	2
Power Supply Way	3
Connection Method and Cautions for Monitor and Camera	4
Installation of Mini Hot Shoe Mount Adapter	6
Menu Operation Instruction	8
Menu Function Instruction	10
Shortcut Menu Column	16
Status Column	16
How to Load LUT	17
Firmware Update	18
Technical Parameters	19
Trouble Shooting	20

## **Foreword**

Thank you for purchasing our 5.5-inch OLED vertical monitor. Please read this manual carefully before using the unit. Have a great experience!

## **Cautions**

- Please avoid the heavy impact and drop onto the ground when move the product.
- The screen of this product is made of glass. Please do not drop the screen towards the ground. Keep away from injury if the screen is broken.
- Keep the product away from the heat source, and avoid the prolonged exposures to the sun as the LCD screen will be damaged.
- To avoid damaging the product, please do not take apart or repair the unit by yourself without the adjustable components in the unit.
- In order to better maintain the LCD screen and protect the cover, please follow the following ways to avoid damages.
  - 1. Please refrain from using the hard objects to hit the screen.
  - 2. Please do not force to wipe the screen.
  - 3. Please do not use the chemical solutions to clean the screen.
  - 4. Please do not spray any detergent on the screen.
  - 5. Please do not write on the screen directly.
  - 6. Please do not stick on the screen.
  - 7. Please simply wipe with a clean soft cloth and make sure no water on the screen.


## **Key Features**

- 5.5-inch AMOLED screen, independent light control, ultimate black performance
- ➤ DCI-P3 100% color gamut, more accurate color presentation
- > 1,000,000:1 ultra-high contrast ratio, bringing you more realistic and

vivid visual experience

- > Full touch screen, easy to setup
- Supporting menu vertical and horizontal switching
- Custom 3D-LUT loaded, preview film look
- > Stereo Earphone output

# **Product Overview**




# **Power Supply Way**


- (1) There is a USB-C power port on the right of monitor, you can power with the accompanied power adapter
- (2) The rear cover of the monitor is equipped with a NP-F battery slot, it can be installed the NP-F series battery
  - The battery models including F970 F960 F950 F930 F770 F750 F730
     F570 F550 F530 and other specifications.

Remark: Please take off the battery from the monitor if you don't use the monitor in a long time.

- Installation and remove of battery
- Insert the battery gently in the direction indicated, then slide it to the left (without releasing). A clicking sound indicates that the battery is securely in place.



2. To remove the battery, press and hold the battery release button while slide the battery to the right, then remove it.




## **Connection Method and Cautions for Monitor and Camera**

## **Preparing before connecting**

- Ensure that both the camera/camcorder and monitor are turned off
- Check if the HDMI interface and cables are clean and intact
- Prepare anti-static wristbands or discharge by touching metal object first
- Ensure that the workbench is clean and stable

#### **Connection of HDMI cable**

- Using the accompanied HDMI/Micro HDMI cable to connect the HDMI IN
   of the monitor and the HDMI Out of the camera(please purchase extra
   HDMI cable if the HDMI cable is not long enough)
- 2. Fix the wire to avoid hanging or pulling it
- 3. Turn on the camera first, and then turn on the monitor. The image of camera viewfinder will displayed on the screen of the monitor.
  - Please set it to Auto or 16:9 if the camera is designed with an HDMI output setting function.
- 4. When shutting down, first turn off the monitor, wait for it to completely shut down, and then turn off the camera.



## **Using cautions**

- When moving the device, be careful not to trip over the wires, which may cause hot plugging or unplugging
- Regularly check whether the HDMI interface and HDMI cables are worn or blocked by foreign objects
- It is recommended to disconnect when not in use to protect the cables and interfaces

## **Physical protection measures**

- Use HDMI cable fixing clips or brackets
- -The wire should have an appropriate margin to avoid being too tight
- -Consider using an L-shaped HDMI connector to reduce the pressure on the HDMI interface

-You can use an HDMI adapter to protect the HDMI interface on the camera and avoid damage to the HDMI interface caused by frequent plugging and unplugging


## **Regular maintenance**

- -Check if there is dust accumulation on the interface
- -Is the equipment voltage stable
- -Confirm that the wire is not damaged or bent
- -Is the fixing device still securely fastened
- -Are all screws securely fastened


These measures can significantly reduce the risk of equipment damage and extend its service life.

# **Installation of Mini Hot Shoe Mount Adapter**


1. Select the direction in which the adapter is mounted according to the shape of hot shoe on the camera



- 2. Align the 1/4 screw of the adapter with the 1/4 screw hole on the device.
- 3. Tighten the adjustment knob of the adapter



- 4. 1 Fully insert the base of the adapter into the universal hot shoe base in the direction shown in the figure.
  - 2 Tighten the rotary table of the adapter to fix it on the camera



Note: If using a camera with a pop-up built-in flash, please turn off the built-in flash of camera. If the camera is designed with a built-in auto flash function, please turn off this function.

Please remove this device from the camera before using the flash.


# **Menu Operation Instruction**


After the monitor is correctly connected to the power supply, the indicator light is on (red). Long press turn on power, the indicator light turns yellow, and after the HDMI signal is input, the indicator light turns green.

After startup, short press **b** button to select to turn the screen touch function on or off.

## **Touch Screen Menu Operation (Vertical mode)**

- ①. Double-click on the screen to open the main menu (show on the left side of the screen) and click on the corresponding menu to display the secondary menu. You can enter the corresponding function option and click directly to select or set. Click the touch screen to exit the menu.
- 2. When the menu is not displayed, swipe up from the bottom of the screen to open the shortcut menu, swipe left or right select the needed function and click on the corresponding menu box to turn on or turn off the corresponding function.
- (3). When the menu is not displayed, on the above side of the screen (1/2 split screen), you can directly adjust the brightness of the screen backlight; on the below side of the screen (1/2 split screen), you can directly adjust the volume.







## **Touch Screen Menu Operation (Horizontal mode)**

- 1. Double-click on the screen to open the main menu (show on the left side of the screen) and click on the corresponding menu to display the secondary menu. You can enter the corresponding function option and click directly to select or set. Click the touch screen to exit the menu.
- 2. When the menu is not displayed, swipe up from the bottom of the screen to open the shortcut menu, swipe left or right select the needed function and click on the corresponding menu box to turn on or turn off the corresponding function.
- ③. When the menu is not displayed, on the left side of the screen (1/2 split screen), you can directly adjust the brightness of the screen backlight; on the right side of the screen (1/2 split screen), you can directly adjust the volume.


### Figure:






# **Menu Function Instruction**

The main menu including 5 parts: Assist, Marker, Image, User, System





#### Assist



	Off On
	Off, On Type: RGB、YUV、Y
	This essential feature assists with the calibration of professional video
	·
	cameras. It shows the overall brightness of the image assisting the
Waveform	video professional in correcting exposure. The waveform feature also
	checks the evenness of the lighting when lighting a chromakey or
	background.
Z	Off, On
	shows how saturated the image is and where the pixels in the image
Vectorscope	land on the color spectrum.
	Y Histogram: Off, On
	RGB Histogram: Off, On
Histogram	
	Y Histogram: A quantitative tool to check the picture brightness,
	display different color for different brightness.
	DCP Histogram: It can display the graphic of color tone distribution
	RGB Histogram:It can display the graphic of color tone distribution,
	can intuitively display the exposure status of the image, and display
	overlapping histograms in red, green, and blue channels
	Off, On
	Color: ( Yellow, Red, Green, Blue, White )
Focus Assist	Peaking Level: you can adjust the peaking level after turning on (1~
	8)
	It highlights the areas that are in focus so you are able to quickly focus
	the camera and not miss crucial shots.
	Off, On
Audio	The Audio Level Meters provide numerical indicators and headroom
Meters	levels.
	Off, On
<b>///</b>	Zebra Level: you can adjust the zebra level after turning on ( $0^{\sim}100$ )
	7 - 7 - 7 - 7 - 7 - 7 - 7 - 7 - 7 - 7 -

Zebra	Areas of the image over a certain threshold are filled with a striped pattern to dramatically highlight areas where too much light is falling on the image sensor.
	Off, On Color: Red, Green, Blue, Gray
Check Field	When enabled, hue and saturation adjusted quickly and accurately
	Off, On Type: Spectrum、ARRI
False Color	An image that depicts an object in colors that differ from those a
	photograph (a true color image) would show.



#### Marker

	Off, On Type: 3x3, 4x4, 5x3, 5x5, 6x4, 6x6
Crosshatch	Color: Yellow, Magenta, Cyan, Red, Green, Blue, White
	The area of the picture can be divided into 9, 16, 15, 25, 24, 36,
	equal grids.
	Off, On
	Type: 70%, 80%, 90%, 16:9, 16:10, 4:3, 5:4, 1:1, 1.91:1.1, 4:5, 9:16,
Safe Areas	1.85:1 ,2.35:1
	Color: Yellow, Magenta, Cyan, Red, Green, Blue, White
+	Off, On
Crosshair	Color: Yellow, Magenta, Cyan, Red, Green, Blue, White
	Off, On
	Type: 16:9、16:10、4:3、1.85:1、2.35:1、2.41:1、1.91:1、

Cinema Guides	5:4、1:1.9
	Color: Yellow, Magenta, Cyan, Red, Green, Blue, White
	Marker Mat Alpha: 0%~75%



Scan Mode	Under Scan, Over Scan
	Off, On
	Type: Auto, 16:9, 16:10, 4:3, 5:4, 1.85:1, 2.35:1,User
Aspect Ratio	Under the "user", you can customize the Video Width (100% ~ 300%),
	Video Height (100% ~ 300%)
	Provides a wide variety of aspect ratio to match different camera
	anamorphic lenses.
	Off, On
	Type: Auto, 1.25X, 1.33X, 1.5X,1.6X, 1.8X, 2.0X, 2.0X MAG
Anamorphic	Allows you to use anamorphic lenses or adapters and see the image
	unsqueezed, even if your camera does not de-squeeze in camera.
	Off, On
Video Flip	
	Off, On
$[oldsymbol{Q}]$	Zoom Times:100%~500%
Zoom Times	It is HD signal in any part, an amplification for high quality close-up.
	Off, On

Image Freeze	
1:1	Off, On
	Enable the filmmaker to check the image from the 1:1 signal source
Pixel to Pixel	without scaling. This feature is essential for capturing optimum detail.



## **User Option**

	Lut Import (SD)
LUT Import	
	Off, On
	LUT List (display the 4 built-in LUT and the imported custom LUT)
	SLOG2
LUT	SLOG3
	LOGC
	VLOG
	LUT is a table for quickly looking up and output specific color data.
	By loading different 3D-LUT tables, it can quickly recombine color
	tone to form different color styles
<b>P</b>	Brightness: 0~100
	Adjust the image brightness
Display Setup	Contrast: 0~100
	Adjustment of the ratio between the brightest and darkest parts of
	the image . When adjusting, pay attention to the sense of hierarchy
	in the image. If the proportion is too large or too small, it can cause
	the image to lose its colorful appearance.

	Caturation 00100
	Saturation: 0~100
	Adjustment of color concentration
	Hue: 0~100
	Sharpness: 0~100
	Backlight: 0~100
	Adjust the screen brightness
	Color Space: REC709, DCIP3, BT2020
(30)	Color Temp.: 5600K, 6500K, 9300K, User
Color	Under the <b>User</b> , the red, green and blue of the image can be
	adjusted (0~255), made the colors of the image achieve your
	favorite.



Language	English、中文、Français、Deutsch、Italiano、Español、日本語、한국、Русский、Português
Screen Mode	Auto Rotary: Off, On Screen Mode:Horizontal, Horizontal Mirror, Vertical, Vertical Mirror
OSD Setup	OSD Time: Always, 5s、 10s、 15s、 20s、 25s  Select the display time of the menu on the screen  OSD Alpha: Off, Low, Middle, High  Adjust the transparency of the menu picture background on the screen
<b>(</b> *)	Off, On 0~100

Volume	Adjusting the speaker volume
[ <b>*</b> ]	Off, On
	The right corner of the monitor will be shown the Power Display icon
Power Display	after turning on
	Current: (display the version number)
	Update: Click to firmware update
Firmware Update	<b>Restore:</b> After clicked "Restore",the system back to original setting.


# **Shortcut Menu Column**



The user can call up the shortcut menu by swipe up from the bottom of the screen, and click on the corresponding menu box to open or set the corresponding function.

Click icon to display the detailed parameters setup, click the hide icon to close detailed parameters; click to browse more shortcut functions.

# **Status Column**



INPUT: Display the resolution of INPUT resolution, e.g.: INPUT HDMI 1920x1080x50p

: Display the status of touch function

System--Power display to turn on or turn off)

# **How to Load LUT**

### 1. SD card format

Support FAT32 or NTFS. For MAC system, the SD card should be formatted in MS-DOS (FAT)

- 2. Max Files Limit Maximum 32 Lut files
- 3. File requirements
  - The LUT file format suffix should be .cube
  - Single file not exceeded to 7.9Mb
  - Support LUT-3D-Size 16,17,32,33,64,65

Remark: LUT file name must be English or Arabic numerals

- 4. Steps for loading
- 4.1 Make sure the SD card correctly insert
- 4.2 Enter main menu "User Option"--LUT Import--Lut Import (SD) to load the monitor will auto detect the SD card
- A. There is no SD Card, the screen will show failed, can try once more, if not work, restart the monitor and try again
- B. There is SD Card, the monitor will erase the exits user's lut fill and show "Initializing", If there is no valid lut file in SD card, the lut will not load. The monitor will show "clean up"
- C. If there is valid lut file in SD card, the monitor will load lut files and show "[n] name. The [n] shows the quantity number. The "name" should in lut files' name. If load successful, the screen will show "complete[n]". [n] Stands for the quantity number for lut files should under 32.

## **Firmware Update**

We usually do not recommend to upgrade casually. If really need, please connect after-sale or other person to get the relevant upgrade file

- Use a SD card with FAT32 or NTFS format, for MAC system, the SD card should be formatted in MS-DOS (FAT). Copy the upgrade file to the SD card.
- 2. Turning on the monitor, insert the SD card to SD card slot of the device (the chip should be faced up when inserting the SD card, and press it after inserting to ensure that the SD card is fully inserted).
- 3. Enter the menu, select **System--Firmware Update--Update**, click "Update" to start to upgrade.

- 4. The monitor will shut down automatically when finished, please reboot manually
- 5. Check whether the latest version

Remark: Please keep the device is powered on in the whole upgrading

# **Technical Parameters**

	ANAOLED E Einch (touch)
Panel Size	AMOLED 5.5-inch (touch)
Resolution	1080 x1920 pixels
Dot Pitch	94.8(W) × 63.2(H) um
Aspect Ratio	9:16
Color Display	16.7M (8 bit)
Frame rate	60Hz
Brightness	550cd/m <sup>2</sup>
Contrast	1,000,000:1
Backlight	LED
Adjustable Backlight	Yes
Input	HDMI 2.0
Output	HDMI 2.0
Audio	3.5mm stereo headphone jack
Other Interface	SD Card Slot (firmware update/LUT file import)
Power In	USB-C Note: please use 5V/2A or more than 2A Type-C power supply

	480i/576i/480p/576p
	720p (60/59.94/50/30/29.97/25/24/23.98)
HDMI Input/ Output	1080i (60/59.94/50)
Support Format	1080p (60/59.94/50/30/29.97/25/24/23.98)
	3840×2160p (60/50/30/29.97/25/24/23.98)
	4096×2160p (60/50/30/29.97/25/24/23.98)
Power Consumption	≦10W
Unit Size (mm)	144x81x23.9 (mm)
Unit Weight	148g
Mount Points	¼-20 thread points (Left, right, top,bottom)
Working Temperature	-20℃~60℃
Storage Temperature	-30℃~70℃

# **Trouble Shooting**

## 1. Only black and white or monochrome picture:

- 1 please check saturation, brightness & contrast adjustment.
- 2 Please check "Check Field" is in black, white or monochrome image or other condition.

## 2.NO Image after put on the power

- 1 Check if signal cable connecting is in good condition.
- 2 Check signal cable connecting, and make sure to use the standard adapter to connect the monitor. If power is supplied by battery, please check if the battery is fully charged.

## 3. Earphone No sound

Check if Volume control do not open, press the volume button, and try to increase the volume.

- If there are still other problems, please contact with our related technologists.
- ★ As we are improving product features and product performance, so if there is any change on the specification without prior notice.